Distortion In Printed Image

Doctor blade too soft

Probably Cause	Possible Solution
Pad	
Wrong shape	Use a different shape
Too soft or too hard	Use different hardness
Image too close to pad edge	Move or replace pad
Cliché	
Etched too deep	Coupled with think ink, the smudging caused is often mistaken for distortion
Wrong orientation	Turn long lines at an angle
Ink	
Too thin	Reduce the amount of thinner
Ink is too thick	Add more thinner
Insufficient mixing of ink and additives	Mix the ink thoroughly before putting it into the ink tray or cup
Material	
Odd shaped surface	Use suitable pad
Other	

Use a firmer doctor blade or convert to inkcup system